

Star Max Deck Light Installation



LVX125MAX

Be sure not to exceed the maximum wattage for the transformer used.



1a. Solid Boards

When drilling your hole into a solid board, use a 1" spade drill bit as shown. Do not drill into the substructure.



1b. Hollow Boards

When drilling your hole into a hollow board, use a 15/16" drill bit as shown. Do not drill into the substructure.



2. Accent Collar

An accent collar is provided. Place the collar over the hole.



3. Feed The Wires

Feed the wires into the wire hole.



4. Press

Press the light firmly into the hole until the flange touches the surface of the board.



5. Connect

Plug the male end into the female end of the last component installed.



6. Complete